

## **General Cleaning Guidelines**

### All Zahner Surfaces

Clean Zahner Surfaces at least once per year to ensure the initial appearance is retained. Use warm soapy water and a clean, soft cotton cloth, followed by a thorough rinse using clean water. Wipe dry with a clean, soft cotton cloth.

If a more aggressive cleaning is required, Isopropyl Alcohol, Windex® Original Glass Cleaner, or Windex Vinegar Glass Cleaner can also be used. Clean and wipe dry with a clean, soft cotton cloth.

Whenever cleaning for the first time, test in an inconspicuous area. If a successful result is obtained, cleaning the rest of the surfaces can begin. Clean the entire surface equally - clean all the way to any edged or joints - to avoid visible differences in appearance.

### Angel Hair® Stainless Steel and GB-60™ Stainless Steel

The use of commercially available cleaners for stainless steel is not recommended, as these typically contain oils that will penetrate into the finish and change its appearance.

Do not use cleaners that contain chlorides (such as bleaches) or abrasives, as these will damage the finish and/or the underlying stainless steel.